Always follow recommendations in manual first	Every outing	Every 20 hrs.	Every 50 hrs.	Every 100 hrs.	Before layup	
ENGINE AND DRIVE						
Check oil/fill	V	V	V	V	V	11
Check transom mounting bolts/jack plate bolts (if equipped)	<b>V</b>	V	V	<b>V</b>	V	
Check propeller and skeg for damage	V	V	V	<b>V</b>	V	
Check cowl air intakes for blockages	<b>V</b>	V	<b>V</b>	<b>V</b>	V	
Check engine operating temperature	<b>V</b>	V	<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check oil pressure	<b>V</b>	<b>V</b>	<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check drive/gearcase for water/particulate/burnt lubricant & refill		V	<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check engine for proper operating RPM @ WOT		V	<b>V</b>	<b>V</b>	V	
Check fuel lines for alcohol and UV degradation			<u> </u>	<u> </u>	<u> </u>	11
Replace fuel/water separating filter			<u> </u>	<u> </u>	<u> </u>	1
Check power trim/tilt fluid, refill if necessary			<u> </u>	<u> </u>	<u> </u>	1
Check engine mounts and swivel/steering bracket for excessive play			<u> </u>	<u> </u>	<u> </u>	22
Lubricate all grease points				<b>V</b>	<b>V</b>	
Coat electrical w/silicone protectant spray				<b>V</b>	V	
Have linkage/synchronization checked				<b>V</b>	<b>V</b>	Ľ
Retorque all accessible bolts/fasteners				<b>V</b>	<b>V</b>	
Touch up paint				<b>V</b>	<b>V</b>	
Check spark plugs and replace as necessary				V		11
Change and check condition of gearcase lube and powerhead oil				V		u
Replace water-pump impeller				<b>V</b>		M
Freat fuel with storage conditioner, fog engine, drain/refill oil, replace oil/fuel filters					V	M
STEERING SYSTEM						M
Check for excessive play/movement	<b>V</b>	V	<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check fluid level/check for leaks/bleed system (hydraulic)			<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check engine free-play and adjust			<b>V</b>	<b>V</b>	V	Ľ
Lubricate all grease points			<b>V</b>	<b>V</b>	<b>V</b>	Ľ
Check for kinks (hydraulic and mechanical) and/or binding (mechanical)				<b>V</b>	<b>V</b>	Ľ
BOAT: INTERIOR, TOPS, SAFETY GEAR, HULL, HARDWARE						Ľ
Check hull for damage; repair if necessary	<b>V</b>	V	<b>V</b>	<b>V</b>	V	2
Check transom for possible cracking	<b>V</b>	V	<b>V</b>	<b>V</b>	<b>V</b>	M
Nash hull and deck	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	
Check registration and inspection to ensure they're up-to-date	<b>V</b>	<b>✓</b>	<b>✓</b>	<b>V</b>	<b>V</b>	
Check bilge pump and auto switch for proper operation	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	Ľ
Check battery(s) for proper charge	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	Ľ
Check all other electrical accessories and systems for proper operation	<b>V</b>	<b>✓</b>	<b>V</b>	<u> </u>	<b>V</b>	Ľ
Check safety gear to ensure it is up-to-date and in good condition	<b>V</b>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	
Check fire extinguishing systems	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	Ľ
Clean and protect interior		<b>✓</b>	<b>✓</b>	<u> </u>	<b>V</b>	Ľ
Clean bilge		<u> </u>	<u> </u>	<u> </u>	<u> </u>	
Nax/polish hull and deck			<u> </u>	<u> </u>	<u> </u>	Ľ
Check top, cover, etc., for condition, proper storage, and clean/protect			<u> </u>	<u> </u>	<u> </u>	Ľ
Check bow and stern eyes for tightness and secure mounting				<u> </u>	<u> </u>	1
Check rubrail for damage and repair if necessary				<u> </u>	<u> </u>	Ľ
Check all cleats, rail fittings, and deck fittings for tightness and secure mounting				<b>V</b>	V	Ľ
FRAILER						
Check coupler mechanism for proper operation, lubricate w/silicone spray	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	
Check safety chains for rust, damage	<u> </u>	V	V	<u> </u>	<b>V</b>	Ľ
Check winch and winch strap; check emergency retention chain/strap	<b>V</b>	<b>V</b>	<b>V</b>	<u> </u>	<b>V</b>	Ľ
Check tiedowns and tiedown eyes	<u> </u>	V	V	<b>V</b>	<b>V</b>	Ľ
Check lights, connector, and wiring harness and repair if necessary	<u> </u>	V	V	V	<b>V</b>	ľ
	<u> </u>	V	<u> </u>	V	<b>V</b>	Ľ
Check tires for proper inflation pressure (including spare), check brakes		V	V	V	<b>V</b>	N
Check tires for proper inflation pressure (including spare), check brakes Check wheel bearings for proper grease level, binding, excessive noise					<b>✓</b>	£
Check tires for proper inflation pressure (including spare), check brakes Check wheel bearings for proper grease level, binding, excessive noise Check suspension for rust, damage, missing bolts; repair if necessary			<u> </u>	<u> </u>	<u> </u>	
Check tires for proper inflation pressure (including spare), check brakes Check wheel bearings for proper grease level, binding, excessive noise Check suspension for rust, damage, missing bolts; repair if necessary Check tires for age, weather checking, low/uneven tread (including spare)		V	V	<i>V</i>	V	Ľ
Check tires for proper inflation pressure (including spare), check brakes Check wheel bearings for proper grease level, binding, excessive noise Check suspension for rust, damage, missing bolts; repair if necessary Check tires for age, weather checking, low/uneven tread (including spare) Check wheel condition for rust, cracks, or bends			V V	V V	V V	1
Check tires for proper inflation pressure (including spare), check brakes Check wheel bearings for proper grease level, binding, excessive noise Check suspension for rust, damage, missing bolts; repair if necessary Check tires for age, weather checking, low/uneven tread (including spare)		<i>V</i>	V V	V V	V	